


The Carrot-Clip Installation Instructions

Your package contains one Carrot-Clip and one battery cap spacer. The spacer insures that the battery makes good contact. Don't forget to install it! Remove the battery cap from your ProPointer. The included battery cap spacer has an adhesive backing. You can either peel and stick the spacer inside of the battery cap, or just drop it inside as is.

Slide the Carrot-Clip over the threads of the battery cap and begin screwing the cap back onto the body of the ProPointer. Align the clip in the position you prefer and snug down the cap until you can no longer move the clip from side to side.



All done. Enjoy!

IMPORTANT! Be sure to remove the Carrot-Clip before submerging your ProPointer in water.